PECVD-Turner05-LS SIN recipe-850A			PECVD1 LS SIN 850A Typical Film Properties
I. Chamber Clean ( wet clean)	2. Chamber (clean+coat)	3.LS SIN Deposition	Calibrated every 2-4 weeks
VET CLEAN	TURCLN	TURNER05	Check for the latest update on UCSB Nanofab WIKI
Vipe clean upper chamber walls with DI	step1: Initial t=10", p=2x10-2 T=250C	step1: Initial t=10"	
Wipe off upper chamber walls with IPA	step2: N2 purge t=30" p=300mT	step2: N2 purge t=30"	
	step3: evacuate, base pressure=2x10-2, t=10"	step3: evacuate, t=10"	
	step4:loop	step4:loop	
	step5:gass stabilization, t=30"	step5: LSSIN gass stabilization, t=30"	LS SIN 850A Typical Film properties
	step6:etch chamber, t=30'	step6:LSSIN deposition	Deposition rate~8.41nm/min
	step7:evacuate, t=10"	Time=10min30sec	Refractive index@632.8nm=1.966
	step8:N2 purge	Temperature=250°C	Stress=230MPa
	step9:evacuate	Pressure=900mT	HF etch rate=60nm/min
	step10:loop	Gass Flow:	Particle count ( min=50, max=250)
	step11:LSSIN gass stabilization	SiH4=150sccm	Mostly small size particles (0.160-0.213)um
Should be t~2min 16sec →	step12:LSSIN deposition (200A coat) , t=2'29.7"	N2=59sccm	Uniformity within the wafer (99.2-99.5)%
	step13:evacuate	NH3=1.53	
	step14:N2purge, t=30"		
	step15:end	Power:	
		RF1=22W	
		step7:evacuate, t=10"	
		step8:N2 purge t=30"	
		step9:evacuate t=10"	
		step10:loop	

