| Mo Sputtering Film using Sputter#3 at RT |              |                     |          |             |           |              |                          |                          |
|--|--------------|---------------------|----------|-------------|-----------|--------------|--------------------------|--------------------------|
| Pressure (mT)                            | DC Power (W) | Ar Flow-rate (sccm) | Time (s) | Height (mm) | Gun Angle | Rotation (%) | Mo Film<br>Thickness (Å) | Sputtering<br>Rate (Å/s) |
| 3  | 200          | 25                  | 1200     | 44          | 4         | 50(~10rpm)   | 2630                     | 2.192                    |

Figure 1 shows the profile of Mo Film.

